

Switch Back to Last Used Tool	Right Click
Pan View	Middle Click (Wheel)
Zoom View	Scroll Wheel

## Editor

New	Ctrl+N
Open	Return
Save	Ctrl+S
Save All	Ctrl+Shift+S
Select All	Ctrl+A
Find	Ctrl+F
Find Next	F3
Find Previous	Shift+F3
Show in File Manager	
Control Panel	Ctrl+Alt+Home
Switch Workspace	
Workspace Settings	Ctrl+,
Rescan Libraries	F5
Library Manager	Ctrl+Alt+M
New Library Element	Ctrl+N
Duplicate	Ctrl+D
New Project	Ctrl+N
Open Project	Ctrl+O
Save Project	Ctrl+S
Project Settings	Ctrl+Alt+T
Project Properties	Ctrl+Alt+R
Net Classes	Ctrl+Alt+N
Grid Properties	F4
Layer Stack	F6
Design Rules	F7
Design Rule Check	F8
Update Project Library	Ctrl+F5
Schematic Editor	Ctrl+Alt+S
New Sheet	Ctrl+N
Rename Sheet	Ctrl+F2
Remove Sheet	Ctrl+Del
Board Editor	Ctrl+Alt+B
New Board	Ctrl+N
Copy Board	Ctrl+D
Remove Board	Ctrl+Del
Show All Planes	
Hide All Planes	
Rebuild All Planes	Ctrl+Shift+R

## Import/Export

Import DXF	
Import EAGLE Library	
Export *.lppz Archive	
Export Image	Ctrl+Shift+I
Export PDF	Ctrl+Shift+P
Print	Ctrl+P
Generate Bill Of Materials	F9
Generate Fabrication Data	F10
Generate Pick&Place Files	F11
Order PCB	F12

## Modify

Undo	Ctrl+Z
Redo	Ctrl+Y   Ctrl+Shift+Z
Cut	Ctrl+X
Copy	Ctrl+C
Paste	Ctrl+V
Move Left	Left
Move Right	Right
Move Up	Up
Move Down	Down
Rotate Counterclockwise	R
Rotate Clockwise	Shift+R
Mirror Horizontally	M
Mirror Vertically	Shift+M
Flip Horizontally	F
Flip Vertically	Shift+F
Snap to Grid	S
Reset All Texts	
Properties	E
Rename	F2
Remove	Del

## View

Zoom to Fit Contents	Ctrl+Home
Zoom In	Ctrl++
Zoom Out	Ctrl+-
Increase Grid Interval	Ctrl+Shift++
Decrease Grid Interval	Ctrl+Shift+-

## Tools

Select	
Draw Line	L
Draw Rectangle	G
Draw Polygon	P
Draw Circle	C
Draw Arc	Shift+C
Add Text	T
Add Name	N
Add Value	V
Add Pin	I
Add SMT Pad	D
Add THT Pad	H
Add Hole	O
Draw Wire	W
Add Net Label	N
Add Component	A
Draw Trace	W
Add Via	V
Draw Plane	N
Measure Distance	Ctrl+M

## Commands

Go To Command Toolbar	Tab
Abort Command	Esc
Layer Up	PgUp
Layer Down	PgDown
Increase Line Width	+
Decrease Line Width	-
Increase Size	*
Decrease Size	/
Increase Drill	Home
Decrease Drill	End
Toggle Auto-Width	.
Toggle Fill	F
Toggle Grab Area	,
Align Left	1
Align Center	2
Align Right	3
Align Bottom	4
Align Center	5
Align Top	6
Horizontal - Vertical	1
Vertical - Horizontal	2
90° - 45°	3
45° - 90°	4
Straight	5
Round	7
Rectangular	8
Octagonal	9

## Components

Resistor	
Inductor	
Bipolar Capacitor	
Unipolar Capacitor	
GND Supply	
VCC Supply	

## Docks

Pages	Ctrl+Alt+G
Electrical Rule Check (ERC)	Ctrl+Alt+E
Design Rule Check (DRC)	Ctrl+Alt+D
Layers	Ctrl+Alt+L
Place Devices	Ctrl+Alt+P

## Window Management

Next Tab/Page	Ctrl+Tab
Previous Tab/Page	Ctrl+Shift+Tab
Close Tab	Ctrl+W
Close All Tabs	Ctrl+Shift+W
Close Window	Alt+F4
Close Project	Ctrl+F4
Close All Projects	Ctrl+Shift+F4
Quit	Ctrl+Q

## Help

About LibrePCB	
About Qt	
LibrePCB Website	
Online Documentation	F1
Keyboard Shortcuts Reference	Ctrl+F1